

# Porsche 987.1 Boxster - Tiptronic Stainless Steel Sports Grille Kit

## Kit Contents: -

1. off Centre Grille



## Centre Mesh Grille Fitting Instructions

1. Fit masking tape around the apertures to protect the paintwork while fitting.
2. Locate LH fixing bracket too aperture (Fig 1).
3. Flex grille so that RH fixing locate behind aperture (Fig 2).
4. Using a thin screwdriver through the mesh lever the 2 brackets tightly into position.
5. Remove the tape and the grilles are now complete.



Fig 1



Fig 2