

Porsche 987.2 Boxster - Tiptronic Stainless Steel Sports Grille Kit

Kit Contents: -

1. off Centre Grille



Centre Mesh Grille Fitting Instructions

- 1. Fit masking tape around the apertures to protect the paintwork while fitting.
- 2. Locate RH fixing bracket too aperture (Fig 1).
- 3. Flex grille so that LH bracket and Centre lower brackets locate behind aperture
- 4. Using a thin screwdriver through the mesh lever the 5 brackets tightly into position (Fig 2).
- 5. Remove the tape and the grilles are now complete.





Fig 1

Fig 2

