

# Porsche 987.2 Boxster - Manual Stainless Steel Sports Grille Kit

## Kit Contents: -

- 1. off Centre Grille
- 2. off No 6 x 2 " Screws



## Centre Mesh Grille Fitting Instructions

1. Fit masking tape around the apertures to protect the paintwork while fitting.
2. Locate Grille Level with aperture as shown in Fig 1.
3. Insert screw into RH side diamond through mesh and tighten down as shown in fig 2 then repeat for opposite end diamond (do not over tighten).
4. Remove the tape and the grilles are now complete.



Fig 1



Fig 2