

Porsche 981 Cayman Stainless Steel Sports Side Grille Kit

Kit Contents: -

- 1. off LH Upper Grille
- 1. off LH Centre Grille
- 1. off LH Lower Grille
- 1. off RH Upper Grille
- 1. off RH Centre Grille
- 1. off RH Lower Grille
- 5. off No6 x 3/4" Screws



Upper Side Mesh Grille Fitting Instructions (Please fit the grilles in this order)

1. Fit masking tape around all of the apertures to protect the paintwork while fitting as shown in fig 1.
2. Locate Grille Level with aperture.
3. Insert the screw into the diamond through mesh and tighten down as shown in fig 2 then repeat to the other screw (do not over tighten).
4. Repeat steps 1, 2 and 3 to the opposite grille.
5. Remove the tape and the grilles are now complete.



Fig 1



Fig 2

Lower Side Mesh Grille Fitting Instructions

1. Fit masking tape around the apertures to protect the paintwork while fitting.
2. Firstly locate the outer part of the grille into the aperture as shown in fig 1.
3. Locate the inner bracket making sure it clips behind the aperture fig 2. (You can use a long thin screw driver to make sure it has clipped in position or by putting your hand through the centre aperture).
4. Once grille is in correct position insert the screw into the diamond through mesh and tighten down (do not over tighten).
5. Repeat steps 1, 2 and 3 to the opposite grille.
6. The grilles are now complete.



Centre Side Mesh Grille Fitting Instructions

1. Fit masking tape around the apertures to protect the paintwork while fitting.
2. Firstly locate the outer part of the grille into the aperture as shown in fig 1 & 2.
3. Locate the inner bracket making sure it clips behind the aperture. (You can use a long thin screw driver to make sure it has clipped in position).
4. Once grille is in correct position insert the screw into the diamond through mesh and tighten down as shown in fig 3 (do not over tighten).
5. Repeat steps 1, 2 and 3 to the opposite grille.
6. The grilles are now complete.

