

Porsche 981 Cayman Manual & PDK & Cayman S Manual Stainless Steel Sports Centre Grille

Kit Contents: -

- 1 off Centre Grille
- 3 off No 6 x 3/4" Screws



Centre Mesh Grille Fitting Instructions

1. Fit masking tape around the apertures to protect the paintwork while fitting.
2. Locate Grille Level with aperture as shown in fig1.
3. Insert the screw into the diamond through mesh and tighten down as shown in fig 2 then repeat to the other two diamonds (do not over tighten).
4. Remove the tape and the grilles are now complete.



Fig 1



Fig 2