
Part No's. ZPR56314



Porsche 981 GTS (All Models) Stainless Steel Sports Grille Set

Kit Contents: -

zun/sport

- 1. off LH Upper Grille
- 1. off LH Lower Grille
- 1. off RH Upper Grille
- 1. off RH Lower Grille
- 4. off Grip Clips



Lower Side Mesh Grille Fitting Instructions (Please install grilles in this order)

- 1. Fit masking tape around the apertures to protect the paintwork while fitting.
- 2. Firstly attach the grip clip too the moulding as shown in fig 1. This will help hold the grille in place and make sure the grille does not push through the aperture.
- 3. Locate the grille centrally in the aperture guiding the outer part of grille in 1st and making sure it is pushed flush against the aperture (fig 2).
- 4. Hold the grille in position then push the grip clip onto the bracket and the plastic aperture (fig 3 & 4) so that they grille and plastic are held together tightly.
- 5. Gently push the outer part of the grille until the bracket clips into position behind the aperture.
- 6. Using a thin screwdriver through the mesh lever all the brackets so they are tightly into position (fig 5).
- 7. Repeat to opposite side grille
- 8. Remove the tape and the grilles are now complete (fig 6).





THANK YOU FOR CHOOSING A ZUNSPORT PRODUCT.





Part No's. ZPR56314

SHEET 2 of 2 Issue 1 Oct 2014







Upper Side Mesh Grille Fitting Instructions

- 1. Fit masking tape around the apertures to protect the paintwork while fitting.
- 2. Offer the grille to aperture and guide the outer bracket behind the aperture then carefully push the grille so that the opposite bracket locates behind the aperture (fig 1).
- 3. Using a thin screwdriver through the mesh lever all the brackets so they are tightly into position (fig 2).
- 4. Remove the tape and the grilles are now complete.





THANK YOU FOR CHOOSING A ZUNSPORT PRODUCT.

