

# Porsche 987.1 & 987.2 Cayman Stainless Steel Sports Side Vent Grille Kit

**Kit Contents: -**

- 2. off Side Vent Grille
- 4. off Upper Bracket
- 4. off M4 x 20mm Cap Screws
- 2. off M3 Toggle Clamp
- 2. off M3 x 40mm Pan Head



**Side Vent Mesh Grille Fitting Instructions**

<https://www.youtube.com/watch?v=CReSKeoufQs>



1. Locate lower fixing bracket behind the aperture (Fig 1) making sure the upper brackets are as shown in fig 2.
2. Carefully guide the grille so that upper brackets & Toggle Clamp locates in between the slats (Fig 3) and hook behind the aperture (Fig 3a).
3. Using a thin screwdriver through the mesh hold the brackets into position then use an Allen key to tighten the brackets (Fig 4).
4. Using a thin screwdriver through the mesh hold and tighten the toggle clamps through the hole as shown in (fig 5).
5. Repeat for opposite side grille.

