

Porsche 718 Boxster & Boxster S & Cayman & Cayman S Stainless Steel Sports Centre Grille

Kit Contents: -

1 off Centre Grille
5 off 2" Screws



Centre Mesh Grille Fitting Instructions

<https://www.youtube.com/watch?v=9w9Un2z-Cs>



1. Fit masking tape around the apertures to protect the paintwork while fitting.
2. Locate Grille Level in the aperture as shown in fig1.
3. Insert the screw into the diamond through mesh and tighten down as shown in fig 2 (Top screws must go in first) and repeat for the next 5 (do not over tighten).
4. Remove the tape and the grilles are now complete.



Fig 1



Fig 2