

Porsche 992 Carrera S (Sport Design Package)

Stainless Steel Sports Grille

Kit Contents: -

- 1. off Centre Grille
- 1. off M4 x 20mm Cap Screw
- 1. off Fixing Bracket
- 1. off ½" Screw



YouTube Tutorial:

<https://www.youtube.com/watch?v=VQ3JRsRLAik>

Centre Mesh Grille Fitting Instructions

(Please note that the centre fixing bracket is only required if you do not have a license plate plinth as this holds the grille in place.)

1. Remove number plate & plinth if applicable (fig 1).
2. Trim the tabs from the plinth (fig 2)
3. Fit masking tape just around the edges of the apertures to protect the paintwork while fitting and so you can mark the screw position.
4. Carefully guide the grille into the aperture and mark the centre bracket position on the masking tape (fig 3,4,5 & 6).
5. Once you have the markings measure 60mm from the back on the aperture and mark the centre (fig 7 & 8).
6. As the screw is in quite a small space it will make it easier if you make a small lead hole using something like a drill bit or pointer (fig 9). Once this is done remove masking tape Fig 10).
7. Screw fixing bracket to moulding using screw provided (Do not overtighten) (fig 11).
8. Carefully guide the Left-hand Side of the grille into the aperture (fig12).
9. Once the Left-hand side is located guide the Right-hand side slightly flexing the grille to allow it to locate behind the aperture (fig 12).
10. Using a screwdriver as shown in fig 13 & 14 push clips down making sure they locate behind the back aperture & grille is secure.
11. Finally fasten the grille to the bracket using the cap screw provided. It will help to use a screwdriver through the mesh to hold the bracket in place whilst tightening using an Allen Key (Do not overtighten) (fig 15 & 16).
12. Remove the tape and the grilles are now complete.

Fig 1



Fig 2



Fig 3



Fig 4



Fig 5



Fig 6



Fig 7



Fig 8



