

Porsche 992 Turbo S Stainless Steel Sports Outer Grille Set

Kit Contents: -

- 1. off Outer RH Side Grille
- 1. off Outer LH Side Grille
- 2. off No5 x 3/4 Screws



YouTube Tutorial: <https://www.youtube.com/watch?v=x0S5UFBcafK>

Outer Lower Side Mesh Grille Fitting Instructions

1. Fit masking tape just around the edges of the apertures to protect the paintwork while fitting.
2. Locate the outer edge of the grille into position ensuring the bracket has located behind aperture as shown in fig 1.
3. Using a long screwdriver push the clips down ensuring they locate behind the aperture (fig 2).
4. Using the screws provided, secure one screw into the edge of the grille, (repeat on both outer grilles (fig 3)).
5. Remove the tape and the grilles are now complete.

