

## Porsche 992 Turbo S Lower Stainless Steel Sports Grille

### Kit Contents: -

1. off Lower Grille
2. off No5 x 3/4 Screw



[YouTube Tutorial; https://www.youtube.com/watch?v=WkVCZnzyu9A](https://www.youtube.com/watch?v=WkVCZnzyu9A)

### Centre Mesh Grille Fitting Instructions

1. Fit masking tape just around the edges of the apertures to protect the paintwork while fitting.
2. Carefully guide the grille into the aperture ensuring it is central in the aperture.
3. Using a screwdriver as shown in fig 2 & 3 secure the grille with the screws, one at either end of the grille.
4. Remove the tape and the grilles are now complete.

