

## Porsche 991.2 Carrera S Stainless Steel Sports Outer Grille Set

## **Kit Contents: -**

off Outer RH Side Grille
 off Outer LH Side Grille

2. off No6 x <sup>3</sup>/<sub>4</sub> Screws

YouTube Tutorial: https://youtu.be/tqhwVlEYzkI





## **Outer Lower Side Mesh Grille Fitting Instructions**

- 1. Fit masking tape just around the edges of the apertures to protect the paintwork while fitting.
- 2. 1st locate the outer edge of the grille into position ensuring the bracket has located on the front edge aperture as shown in fig 1.
- 3. Using an Allen key or something similar lever the grille outwards through the mesh whilst applying pressure to the inner edge on the grille to allow the bracket to clip behind the aperture.
- 4. Using a long screwdriver push the centre clips down ensuring they locate behind the aperture and repeat for the side clips fig 3.
- 5. Once grille is in position insert screw through mesh diamond to secure to the car fig 4.
- 6. Remove the tape and the grilles are now complete.









