

## Porsche 718 Boxster / Cayman Stainless Steel Sports Outer Grille Set

## **Kit Contents: -**

off Outer RH Side Grille
off Outer LH Side Grille





## **Outer Side Mesh Grille Fitting Instructions**

https://www.youtube.com/watch?v=tC\_ymwJM42o

- 1. Fit masking tape just around the edges of the apertures to protect the paintwork while fitting.
- 2. 1st locate the outer edge of the grille into position ensuring the bracket has located behind the aperture as shown in fig 1, 2 & 3.
- 3. Guide the opposite side of the grille into the aperture making sure the clip is hooked behind the aperture then using a long screwdriver push the clips down ensuring they have clipped and engaged behind the apertures.
- 4. Remove the tape and the grilles are now complete.









