

Porsche 992 Carrera (C2, C2S, C4, C4S) With Front Driving Camera Stainless Steel Sports Centre Grille

Kit Contents: -

1. off Centre Grille
2. off No6 x ¾ Screws



YouTube Tutorial;

<https://www.youtube.com/watch?v=cu9QGcgylsI>



Centre Mesh Grille Fitting Instructions

1. Remove number plate & plinth if applicable.
2. Fit masking tape just around the edges of the apertures to protect the paintwork while fitting.
3. Carefully guide the grille into the aperture (fig 1) and Insert the ¾" screw into the diamond through mesh and tighten down as shown in fig 2 then repeat to the other side (do not over tighten).
4. Remove the tape and the grilles are now complete.

