

Porsche Macan S Lower Stainless Steel Sports Grille

Kit Contents: -

1. off Lower Grille



YouTube Tutorial: <https://www.youtube.com/watch?v=X2JA-9ry1CI>

Lower Mesh Grille Fitting Instructions

1. Fit masking tape just around the edges of the apertures to protect the paintwork while fitting.
2. Carefully guide the grille into the aperture making sure it is centralized in the aperture (fig 1)
3. Ensure the brackets have clipped behind the aperture. You can use a long thin screwdriver to make sure the brackets are clipped in position (fig 2,3)
4. Follow this along the grille from the left-hand side to the right.
5. Remove the tape and the grilles are now complete.

