

RENAULT TRAFIC VAN MY 07-10

Stainless Steel Centre Sports Grille

Kit Contents: -

1 off Centre Grille

Tools Required: -

Masking Tape
Phillips Screwdriver
Thin Flat Screwdriver

**Mesh Grille Fitting Instructions**

1. It is advised that masking tape is used to protect the original trim whilst fitting. Position the tape so that it can easily be removed after fitting.
2. Centralise the grille to the aperture, locate the 2 upper pins in the slots in the bumper.
3. Push the bottom of the mesh grille forward to allow the clips to locate behind the original plastic grille.
4. If necessary the clips can be secured by using a thin flat screwdriver whilst applying light pressure to the front of the grille.
6. Remove the masking tape and assembly is complete.