

# RENAULT TRAFIC VAN MY 07-10

## Stainless Steel Lower Sports Grille

**Kit Contents: -**

1 off Lower Grille

**Tools Required: -**

Masking Tape  
Thin Flat Screwdriver

**Mesh Grille Fitting Instructions**

1. It is advised that masking tape is used to protect the original trim whilst fitting. Position the tape so that it can easily be removed after fitting.
2. Centralise the grille to the aperture, locate the 2 lower clips behind the original grille.
3. Push the top of the mesh grille forward to allow the clips to locate behind the original plastic grille.
4. If necessary the clips can be secured by using a thin flat screwdriver whilst applying light pressure to the front of the grille.
6. Remove the masking tape and assembly is complete.