

SUBARU IMPREZA

Stainless Steel Lamp Cover Grilles

Kit Contents: -

- 1. off LH Grille
- 1. off RH Grille

Tools: -

Masking Tape

Mesh Grille Fitting Instructions

1. Clean aperture
2. Fit Masking tape around the edge of aperture to protect paint.
3. Locate Upper hooks into slotted holes in between the black insert and the bumper.
4. Push the lower part of the grille into position, pushing the spring clip and bracket firmly home. (To remove the grille for service this bracket will have to be levered out with a thin flat screwdriver)
5. Repeat the process on the other side.
6. Remove the masking tape and the grilles are complete

