

SUBARU IMPREZA (Hawk-Eye)

Stainless Steel Upper Mesh Grille Set

Kit Contents: -

- 1. off Centre Mesh Grille
- 1. off LH Mesh Grille
- 1. off RH Mesh Grille
- 2. off Round Spring Clips

**Tools: -**

- Short PS2 Screwdriver
- Flat Head Screwdriver
- Masking Tape

Mesh Grille Fitting Instructions

1. Open Bonnet
2. Fit Masking tape around the front edge of the bumper where it meets the plastic of the grille to protect the paint as they are removed.
3. Remove the plastic fixings from the top of the grilles.
4. Unclip the side fixings and the lower grille fixings will pull out of the bottom with a little effort.
5. Now that the sides are out it allows a better access to remove the Centre grille, you can get to the plastic clips to push them off.
6. Unscrew the inner mouldings from the plastic grille assemblies.
7. Remove the existing metal mesh. (If you want to refit the existing Sti badge, carefully remove the spring clips for the back, be careful not to damage the pegs as you will need them for refitting)
8. Locate the new meshes centrally in the inner moulding from the back of the grille, hooking it inside the two tabs at the top.
9. Trial fit the parts into the position so that you can get the correct position for the Sti badge and check the line up of the mesh.
10. Refit the Sti Badge using the new fixings supplied.
11. Re-assemble the upper grilles with the new mesh.
12. Push the grille assemblies back into the bumper until the plastic clips click into position.
13. Replace the plastic fixings from the top of the grilles.
14. Your grilles are now complete.

