

SUBARU IMPREZA

Stainless Steel Sports Grille lower

Kit Contents: -

- 1. off Lower Grille
- 4. off U Clips

Tools: -

- Torch
- Drill 4mm
- Philips screwdriver

**Mesh Grille Fitting Instructions**

1. Remove Number plate
2. Line up the grille with the aperture and place masking tape into aperture in line with the lower 4 pins
3. Mark 4 lines 55 mm from the step inside the aperture towards the front of the grille onto the masking tape with a pencil or pen.
4. Locate the grille to the outside of the aperture and mark the position of the pins onto the tape.
5. Transfer this position to the previously marked 55mm lines.
6. Drill the 4 positions with the 4mm drill.
7. Place the grille into the holes to check the position. (If the grille is not central or the pins do not line up completely slot out the holes a little until this is corrected. **DO not slot the holes forwards or backwards, just side to side.**)
8. Check and mark the position of the upper brackets and fit the U Clip brackets to the holes in the bumper to coincide with the positions.
9. Remove all of the masking tape.
10. Locate the grille back into the lower holes and carefully push the upper parts of the grille into the aperture so that all of the brackets engage with the U Clip bracket.(adjust bracket angle if necessary as they may have moved in transport)
11. Push the brackets into the U clip brackets until the grill clicks into position and is even along the length.
12. Refit Number Plate

