

SUBARU IMPREZA 2008 STi

Stainless Steel Upper Mesh Grille

Kit Contents: -

1. off Mesh Grille
2. off Round Spring Clips

**Tools: -**

- Short PS2 Screwdriver
- Flat Head Screwdriver
- Masking Tape

Mesh Grille Fitting Instructions

1. Open Bonnet
2. Fit Masking tape around the front edge of the bumper where it meets the black plastic of the grille to protect the paint.
3. Remove the plastic fixings from the top of the grille and the bumper
4. Pulling the bumper top forward to allow access, remove the 4 screws from the back of the grille. (The screws are difficult to locate as the two inner ones cannot be seen. The screws are only short and only locate by a few threads. It would be advisable to get someone to hold the bumper out while you remove the screws)
5. Now that the screws are out unclip the side fixings and the lower grille fixings will pull out of the bottom with a little effort.
6. Unscrew the inner moulding from the upper plastic grille assembly.
7. Remove the existing metal mesh. (If you want to refit the existing Sti badge, carefully remove the spring clips for the back, be careful not to damage the pegs as you will need them for refitting)
8. Locate the new mesh centrally in the inner moulding from the back of the grille, hooking it inside the two tabs at the top.
9. Trial fit the part into the upper grille so that you can get the correct position for the Sti badge and check the line up of the mesh.
10. Refit the Sti Badge using the new fixings supplied.
11. Re-assemble the upper grille with the new mesh.
12. Push the grille assembly back into the bumper until the plastic clips click into position.
13. Re-fit the 4 screws into the back of the grille being careful not to drop them.
14. Replace the plastic fixings from the top of the grille and the bumper.
15. Your grille is complete.

