

SUBARU IMPREZA STI

Stainless Steel Sports Grille lower

Kit Contents: -

1. off Lower Grille

Tools: -

- Torch
- Long flat screwdriver



Body Protection for Fitment of Grilles: -

- Place masking tape onto bumper surface where the brackets will push into place. This will protect the paint and plastic from scratching. Fold the masking tape over so that the tape will not stick to the bumper where the grille actually contacts, this makes it easy to slide out once the grille is in place.



Fold tape



Fix tape



Remove tape after bumper fitment

Mesh Grille Fitting Instructions

1. Locate the upper hooks of the grille into position.
2. Carefully feed in the remaining clips and the lower half of the grill. Into the aperture until the long lower clips hook around the plastic moulding at the back and the shorter stops locate on the step inside the aperture. (Check with a torch that all of the brackets have engaged. If there are any that have not hooked into position use a long screwdriver to put pressure on the top of the bracket while putting pressure on the front of the grille)

3. Make sure the front of the grille looks even with the front of the aperture
4. Remove the masking tape and the grille is complete.

