

SUBARU IMPREZA 2008 WRX Stainless Steel Lower Mesh Grille

Kit Contents: -

- 1. off Mesh Grille
- 6. off No. 6 x 3/4" Screws



Tools: -

- PS2 Screwdriver
- Masking Tape

Mesh Grille Fitting Instructions

1. Place masking tape around the aperture 5mm away from the existing plastic grille
2. Place new grille into aperture over existing grille.
3. Fix into position using the 6 screws provided. (Do not over tighten as this will tear threads in the plastic surround, Only tighten until the grille is held back against the original grille without movement)
4. Remove the masking tape
5. Your grille is complete.

