

SUBARU IMPREZA

Stainless Steel Sports Grille lower

Kit Contents: -

- 1. off Lower Grille
- 4. off No. 6 3/4" screws



Tools: -

- Torch
- Drill 4mm
- Philips screwdriver

Mesh Grille Fitting Instructions

1. Remove Number plate
2. Line up the grille with the aperture and place masking tape into aperture in line with the lower 3 pins
3. Mark 70 mm from the step inside the aperture towards the front of the grille onto the masking tape with a pencil or pen.
4. Locate the grille to the outside of the aperture and mark the position of the pins onto the tape.
5. Transfer this position to the 70mm line.
6. Drill the 3 positions with the 4mm drill.
7. Place the grille into the holes to check the position. (If the grille is not central or the pins do not line up completely slot out the holes a little until this is corrected. **DO not slot the holes forwards or backwards, just side to side.**)
8. Remove the masking tape.
9. Locate the grille back into position.
10. Screw the 4.off black screws into position through the washers in the upper section of the mesh. (Tighten the screws until the grille is back to the body. Do not over tighten)
11. Refit the number plate and the grille is complete

