

Toyota Supra Stainless Steel Sports Lower Centre Grille Kit

Kit Contents: -

1. off Lower Centre Grille



Tools Required

- Screwdriver

Grille Fitting Instructions

1. Using Masking Tape protect painted body work around the area where the grille is to be fitted.
2. Remove the upper plastic bumper fixings from the top of the aperture. Keep them for refitting at the end.
3. Lifting the lower bumper retaining strip a little slide the lower fixing brackets into position between the retaining strip and the bumper.
4. Push the grille back into the aperture until the upper brackets line up with the holes in the top of the aperture.
5. Refit the plastic rivets through the new brackets into the bumper.
6. Remove the tape.
7. Your grille is now complete.

