

Toyota GR Supra A90 Centre Stainless Steel Sports Grille

Kit Contents: -

- 1. off Centre Grille
- 2. off ¾ Screws
- 2.off 30mm Cap Screws
- 2.off Retaining Brackets



[YouTube Tutorial:](#)

Centre Mesh Grille Fitting Instructions:

1. Fit masking tape just around the edges of the apertures to protect the paintwork while fitting.
2. Fit the retaining brackets through either side of the grille at the top of the grille (fig 1).
3. Offer the grille to the aperture and locate the grille ensuring it is central (fig 2).
4. Once the grille is in place and central, keep pressure on grille and tighten the retaining brackets. (use a screwdriver through the mesh) (fig 3 & 4).
5. Using the screws provided, secure the grille near to the lower R/H and L/H side (DO NOT OVER TIGHTEN) (fig 5)
6. Remove the tape and the grilles are now complete.



