

VW T5 Van

Stainless Steel Sports Upper Grille Kit

Kit Contents: -

- 1. off LH Side Grille
- 1. off RH Side Grille
- 4. off Screws $\frac{3}{4}$ "



Mesh Grille Fitting Instructions

1. Open the Bonnet
2. Offer the Mesh Grilles over the existing plastic grille, allowing the bottom Brackets to pass inside the aperture.
3. Push the grilles back into position so that the grilles fit evenly in the aperture
4. Screw into position using the screws provided through the mesh and the diamond washers into the vane of the grille. (Do not over tighten as this will strip the plastic thread formed by the self tapping screw)
5. The grilles are now complete.



Washer for screw fitment attached to mesh

