

VW T5 Van

Stainless Steel Sports Lower Grille Kit

Kit Contents: -

- 1. off Centre Grille
- 1. off LH Side Grille
- 1. off RH Side Grille
- 3. off Screws 1 ½"



Centre Mesh Grille Fitting Instructions

1. Protect Aperture with masking tape 5mm away from the back edge of the moulding where the grille will fit
2. Offer the Mesh Grilles over the existing plastic grille, and screw in position using the screws provided through the mesh and the U shaped diamond washers into existing grille. (Do not over tighten as this will strip the plastic thread formed by the self tapping screw)
3. Remove the masking tape
4. The grille is now complete.



Screw 3 places through U Washer

Side Mesh Grille Fitting Instructions

1. Protect Aperture with masking tape 5mm away from the back edge of the moulding where the grille will fit.
2. Locate the small inside hook into the aperture.
3. Depressing the spring clip push the grille back into position until the outside clip hooks behind the bumper aperture.
4. Check that the hook and clips are holding firm. (If they have not fully engaged you can lever them into position using a thin screwdriver from the front through the mesh)
5. Remove the tape
6. The grille is complete and repeat on the other side.

