

Part No's. ZVW38009

Page 1 of 2 Iss 1 Apr 2013

<u>VW T5 Facelift Van</u> <u>Stainless Steel Sports Side Grille Kit</u>

Kit Contents: -

- 1. off LH Upper Grille
- 1. off LH Centre Grille
- 1. off LH Lower Grille
- 1. off RH Upper Grille
- 1. off RH Centre Grille
- 1. off RH Lower Grille
- 6. off No 6 x $\frac{1}{2}$ " Screws



Upper Side Mesh Grille Fitting Instructions

- 1. Fit masking tape around the apertures to protect the paintwork while fitting.
- 2. Locate the grille to the aperture and fix the grille to the plastic using the screws provided as shown in fig 1 & fig 2.
- 3. The Gilles are now complete.







THANK YOU FOR CHOOSING A ZUNSPORT PRODUCT.



Part No's. ZVW38009

Page 2 of 2 Iss 1 Apr 2013

Lower Side Mesh Grille Fitting Instructions

- 1. Fit masking tape around the apertures to protect the paintwork while fitting.
- 2. Firstly locate the inner bracket making sure it clips behind the aperture fig 1.
- 3. Fix the grille to the plastic using the screws provided as shown in fig 1.
- 4. The grilles are now complete





Fig 1



Centre Side Mesh Grille Fitting Instructions

- 1. Fit masking tape around the apertures to protect the paintwork while fitting.
- 2. Firstly locate the outer hook behind the aperture fig 1.
- 3. Then guide the inner bracket behind the aperture until it clips into position fig 2. You can use a long thin screw driver to make sure it has clipped in position
- 4. The grilles are now complete.



Fig 1







THANK YOU FOR CHOOSING A ZUNSPORT PRODUCT.