

VW T5 Carvelle / California Van Stainless Steel Sports Lower Grille

Kit Contents:

- 1 off Lower Grille
- 4 off No 6 x 1 ½" Screws



Tools Required:

- Masking Tape
- Phillips Screwdriver

Lower Mesh Grille Fitting Instructions

1. Fit masking tape around the apertures to protect the paintwork while fitting.
2. Locate grille to the aperture and guide upper centre bracket through the aperture as shown in fig 1.
3. Carefully push and guide the lower centre bracket behind the aperture and check they have engaged properly by using a thin screw driver as shown in fig 2.
4. Once the grille is securely in position fix the grill to the plastic using the 4 screws as shown in fig 3.
5. The Grilles are now complete.



Fig 1



Fig 2



Fig 3