


ITEM NO.	PART NUMBER	QTY.
1	FRM-05	1
2	Pair of Modified Premium Runners	1
3	Premium Wide Handle	1
4	M8 x 16mm Button Head Bolt	4
5	M8 Rear Slot Washer	2
6	M8 x 20mm Button Head Bolt	4
7	Seatbelt Bracket (Variable Dependant on Seat Model)	1
8	Spacer Bar	1
9	Seatbelt Receiver (If Required)	1
10	7/16" x 20mm Hex Bolt	1
11	FRM-05 M10 Rear Washer	2

FRM-05 at 405mm



NOTE: This drawing is configured for UK Driver's Side. For UK Passenger Side, the Spacer Bar and the Seatbelt Brackets must be on opposite sides in relation to this drawing. Therefore, a Left-Handed Seatbelt Bracket will be required.

When fixing this frame to the vehicle's floor, use the M10 Washers provided on BOTH rear fixing points.