


ITEM NO.	PART NUMBER	QTY.
1	FRM-27	1
2	Premium Wide Handle	1
3	Pair of Premium Runners	1
4	M8 Rear Slot Washer	2
5	M8 x 16mm Button Head Bolt	4
6	M8 x 20mm Button Head Bolt	4
7	Spacer Bar	1
8	Seatbelt Bracket (Variable Dependant on Seat Model)	1
9	OE Seatbelt Receiver	1
10	7/16" x 20mm Hex Bolt	1
11	M10 Form G Washer	2
13	7/16" HS Steel Washer	1
14	Yaris HS Steel Spacer	1

FRM-27 at 405mm



NOTE: This drawing is configured for UK Driver's Side. For UK Passenger Side, the Spacer Bar and the Seatbelt Brackets must be on opposite sides in relation to this drawing. Therefore, a Left-Handed Seatbelt Bracket will be required.

When fixing the frame to the floor, use OE bolts through M10 Form G Washers on BOTH slotted holes, on the 'sill side' of the Subframe.