


Cobra Seats Double Locking Runner Installation Guide



Step 1

Remove bolts from seat base and place these to one side as you will require these later.

Step 2

Make sure you are aligning the runners with the correct bolt hole pattern of the seat, otherwise the handle will not fit correctly.

Cobra runners are designed for seats with a side-to-side hole spacing of 292mm or 405mm for the narrow and wide versions respectively, and front to back hole spacing of 330mm.

Step 3

Extend both runners as shown to expose the mounting holes. You will need to use the handle to unlock the mechanism and separate the upper and lower parts of the runner.

Step 4

Take one of the extended runners and place it on the base of the seat. The wider part of the runner is the top section and this fixes to the seat (see exploded diagram for details). The 'clips' for the runner handle should be closest to the front of the seat - you should end up with the handle at the front of the seat with the handle releasing the mechanism and allowing you to move the seat backwards and forwards when you pull it up.

Step 5

Insert the seat bolt through one end of the runner and lightly tighten.

Step 6

Extend the runner in the opposite direction and repeat step 5, then fully tighten both bolts. Repeat steps 5 and 6 for the opposite runner.

Step 7

Once both runners are in place and the bolts have been tightened the handle is ready to be fitted. Locate the handle onto the pin on one side of the runners. Compress the handle and locate the handle onto the pin on the opposite side. The handle should sit inside the clips on both sides of the runners.

Please note that the rectangular washers in the runner bolt kit are to be used to fix the rear bolts of the runners to either a subframe or the chassis of the car (see exploded diagram).

When fitting seats with runners into your car we always recommend fitting the runners to the seat first, as detailed in the steps above. To bolt the runners to your car's chassis or subframe move the seat as far forwards as possible on the runners then use the bolts provided with the runners to fix the runners to the chassis or subframe. Once the rear bolts are secured move the seat backwards on the runners and repeat the process for the front bolts.